


QUICK USER MANUAL  
RASHA PROFESSIONAL A/S

# BULLET

P I N S P O T



**RASHA** | Professional

## Edition Notes

The **Bullet Zoom pinspot**, User Manual Rev. 1 covers the description, safety precautions, installation, programming, operation, and maintenance of the **Bullet Zoom Pin spot**. Rasha released this edition of the **Bullet Zoom pinspot** User Manual in January 2017.

## Trademarks

Rasha® is a registered trademark of RASHA PROFESSIONAL A/S. (d/b/a RASHA® or Rasha). The RASHA® logo in its entirety including the RASHA® name and the Globe with Rings, and all other trademarks in this manual pertaining to services, products, or marketing statements are owned or licensed by RASHA®. Any other product names, logos, brands, company names, and other trademarks featured or referred to within this document are the property of their respective trademark holders.

## Copyright Notice

RASHA owns the content of this User Manual in its entirety, including but not limited to pictures, logos, trademarks, and resources. © Copyright 2015 RASHA. All rights reserved. Electronically published by Rasha in the United States of America.

## Manual Use

Rasha authorizes its customers to download and print this manual for professional information purposes only. Rasha expressly prohibits the usage, copy, storage, distribution, modification, or printing of this manual or its content for any other purpose without written consent from Rasha.

## Document Printing

For better results, print this document in color, on letter size paper (8.5 x 11 in), double-sided. If using A4 paper (210 x 297 mm), configure your printer to scale the content accordingly.

## Intended Audience

Any person in charge of installing, operating, and/or maintaining this product should completely read through the guide that shipped with the product, as well as this manual, before installing, operating, or maintaining this product.

## Document Revision

The **Bullet Zoom Pinspot** User Manual Rev. 1 supersedes all previous versions of this manual. Discard any older versions of this manual and replace with this version. Go to [www.rashaprofessional.com](http://www.rashaprofessional.com) for the latest version.

| Author    | Date      | Editor | Date |
|-----------|-----------|--------|------|
| Ram Magar | 1/30/2017 |        |      |

# Table of Contents



|                                 |           |  |           |
|---------------------------------|-----------|--|-----------|
| <b>1. Before You Begin.....</b> | <b>4</b>  | <b>5. Technical Specifications .....</b> | <b>12</b> |
| What Is Included .....          | 4         | <b>Technical Specification .....</b>     | <b>12</b> |
| Claims .....                    | 4         | Returns .....                            | 13        |
| Manual Conventions .....        | 4         | Contact Us .....                         | 14        |
| Symbols .....                   | 4         |  |           |
| Safety Notes .....              | 5         |  |           |
| Personal Safety .....           | 5         |  |           |
| Mounting And Rigging .....      | 5         |  |           |
| Power And Wiring .....          | 5         |  |           |
| Operation .....                 | 5         |  |           |
| <br><b>2. Introduction.....</b> | <b>6</b>  |  |           |
| Description .....               | 6         |  |           |
| Features .....                  | 6         |  |           |
| Overview .....                  | 7         |  |           |
| <br><b>3. Setup.....</b>        | <b>8</b>  |  |           |
| AC Power .....                  | 8         |  |           |
| AC Plug .....                   | 8         |  |           |
| Mounting .....                  | 9         |  |           |
| Orientation .....               | 9         |  |           |
| Rigging .....                   | 9         |  |           |
| <br><b>4. Operation.....</b>    | <b>10</b> |  |           |
| Menu Map .....                  | 10        |  |           |
| Manual Zoom & Angle.....        | 11        |  |           |

## What Is Included

- Bullet Zoom Pin Spot
- Charger
- IR Remote
- Quick reference guide

## Claims

Carefully unpack the product immediately and check the box to make sure all the parts are in the package are in good condition. If the box or the contents (the product and included accessories) appear damaged from shipping or show signs of mishandling, notify the carrier immediately, not Rasha. Failure to report damage to the carrier immediately may Void your claim. In addition, keep the box and contents for inspection.

For other issues, such as missing components or parts, damage not related to shipping, or concealed damage, file a claim with Rasha within 7 days of delivery.

## Manual Conventions

| Convention | Meaning         |
|------------|-----------------|
| <b>A</b>   | Channel A       |
| <b>B</b>   | Channel B       |
| <b>C</b>   | Channel C       |
| <b>D</b>   | Channel D       |
| <b>0</b>   | Brightness 0 %  |
| <b>25</b>  | Brightness 25%  |
| <b>50</b>  | Brightness 50%  |
| <b>100</b> | Brightness 100% |

## Symbols

| Symbols | Meaning |
|---------|---------|
|         |         |
|         |         |
|         |         |
|         |         |

## Safety Notes

Read all the following Safety Notes before working with this product. These notes include important information about the installation, usage, and maintenance of this product. This product contains no user-serviceable parts. Any reference to servicing in this User Manual will only apply to properly trained Rasha certified technicians. Do not open the housing or attempt any repairs. All applicable local codes and regulations apply to proper installation of this product.

## Personal Safety

Avoid direct eye exposure to the light source while the product is on. Always disconnect this product from its power source before servicing. Always connect this product to a grounded circuit to avoid the risk of electrocution. Do not touch this product's housing during operation because it may be very hot.

## Rigging

This product is for indoor use only! To prevent risk of fire or shock, do not expose this product to rain or moisture. (IP20) CAUTION: When transferring product from extreme temperature environments, (e.g. cold truck to warm humid ballroom) condensation may form on the internal electronics of the product. To avoid causing a failure, allow product to fully acclimate to the surrounding environment before connecting it to power. Mount this product in a location with adequate ventilation, at least 20 Inches (50 cm) from adjacent surfaces. Make sure there are no flammable materials close to this product while it is operating. Always carry this product by the body. Do not carry from the head.

## Power And Wiring

Always make sure you are connecting this product to the proper voltage in accordance with the specifications in this manual or on the product's specification label. Never connect this product to a dimmer pack or rheostat. Never disconnect this product by pulling or tugging on the power cable.

## Operation

Do not operate this product if you see damage to the housing, lenses, or cables. Have the damaged parts replaced by an authorized technician at once. To eliminate unnecessary wear and improve its lifespan, during periods of non-use completely disconnect the product from power via breaker or by unplugging it. Do not cover the ventilation slots when operating to avoid internal overheating. Do not aim this product toward the Sun. The lenses could concentrate the solar energy and cause internal overheating. The maximum ambient temperature is 113 °F (45 °C). Do not operate this product at a higher temperature. In case of a serious operating problem, stop using this product immediately!

| Use on Dimmer   | Auto Programs             |
|-----------------|---------------------------|
| Outdoor Use     | Auto-Ranging Power Supply |
| Sound-Activated | Replaceable Fuse          |
| DMX             | User-Serviceable          |
| Master/Slave    |                           |

**The term "DMX" used throughout this manual refers to the DMX512 digital data transmission protocol**

# INTRODUCTION



**RASHA** | Professional

## Features

- Built in IR Wireless
- Create rich 2700K Warm white color @ variable brightness
- Built in Battery, Runs for 6 hours on single charge
- Magnatic Surface and compact design
- 
- Set up and tear down in a fraction of the time by eliminating the need for DMX or power cables
- Enhance light shows with adjustable electronic dimmer effects
- Compact design easily fits inside sticks of truss or stand free.
- 
- 



## Description

Rasha Bullet Zoom battery operated pinspot(Bullet) makes all the ways you're used to pinspotting more convenient. And because it sits anywhere of you stage, it can produce soft edge projection on any object, For example, you'll feel a gentle highlight on your party table, flowers, cakes. Rasha Bullet also lets you stick on many metal surface and bend the projection angles, connect with your favorite object or people in fun, spontaneous ways. Most easy, compact pinspot made ever, New battery powered pinspot lights is a bright with a sharp parallel beam that cuts through the air and across video with ease. Built in Manual Zoom function allow user to set or produces cool perfectly parallel, laser-like beam, mid-air effects with an incredible output and surface coverage. This fixtures ideal for the show, events and club where objects should be highlighted through pin spotlight. Fixture introduces powerful magnet, plastic neck(Glue Snack), narrow angle lens, battery powered and 4 fixtures in a group separately controllable IR remote controllable function.

Powerful Magnet of the bottom surface helps fixture to install in any magnetic surface, whereas plastic neck it helps to project the fixture as any beam angle. Built in battery power system makes fixture Better or easy for operate, use can use the fixture in full brightness about 6 hours..

Fixture available with Anodize Black and Natural Aluminum. In each group user can set 4 fixtures, such Fixture A, Fixture B, Fixture C and Fixture D, user can control those fixtures separately from 1 remote control. It's easy and ideal fixture for party, events, Hotels, Art Gallery, clubs or stage program.

# OVERVIEW



# SETUP



## Power Supply Charger



Each **Bullet Zoom** has an external auto-ranging charger that works with an input voltage range of 100 to 240 VAC, 50/60 Hz. To determine the power requirements for each **Bullet Zoom** refer to the label affixed to the product. You can also refer to the Technical Specifications chart in this manual. The listed current rating indicates the maximum current draw during normal operation. For more information, you may download Sizing Circuit Breakers from the Rasha website: [www.rashaprofessional.com](http://www.rashaprofessional.com)



Always connect this product to a protected circuit with an appropriate electrical ground to avoid the risk of electrocution or fire. To eliminate unnecessary wear and improve its lifespan, during periods of non-use completely disconnect the product from power via breaker or by unplugging it.

Never connect this product to a rheostat (variable resistor) or dimmer circuit, even if the rheostat or dimmer channel serves only as a 0 to 100% switch.

## AC Plug

The **Bullet Zoom** comes with a power input cord terminated with an Edison Connector (U.S. market). If the power input cord that came with your product has no plug, or if you need to change the Edison plug, use the table below to wire the new plug.

| Connection | Wire (U.S.) | Wire (Europe) | Screw Color     |
|------------|-------------|---------------|-----------------|
| AC Live    | Black       | Brown         | Yellow or Brass |
| AC Neutral | White       | Blue          | Silver          |



# MOUNTING



**Before mounting this product, read and follow the Safety Notes. For our Rasha® Professional line of mounting clamps, go to <http://rashaprofessional.com/en/accesories>**

## Orientation


Always mount this product in a safe position and make sure there is adequate room for ventilation, configuration, and maintenance

Rasha recommends using the following general guidelines when mounting this product.

## Rigging

- Bullet zoom it comes with built in magnet surface, you can easily stick over any metal surface. If you need to install over the glass or white surface magnet may leave the black marks over its surface. customer are requested to put a part of fabrik
- When selecting an installation location, consider easy access to this product for operation, programming adjustments, and routine maintenance.
- Make sure to mount this product away from any flammable material as indicated in the Safety Notes.
- Never mount in places where rain, high humidity, extreme temperature changes, or restricted ventilation may affect the product.
- If hanging this product, make sure that the mounting location can support the product's weight. See the Technical Specifications for the weight-bearing requirements of this product.
-

# MENU MAP




- Bullet it has 8 dial selector switch A,B,C,D,0,25,50,100 as shown in left side picture
- A,B,C,D- those stand for the channel or group.
- 0,25,50,100 those stand for brightness
- User can turn the indicator switch clockwise or anti clockwise and pointout towards A ,B,C or D
- Once you set the channel A,B,C,D , user can rotate the indicator switch anti clockwise and set the desired brightness
- 0 will work as turnoff switch, if user set the indicator switch at "0" fixture will completely shutdown, it will help the battery drain
- User can manually set the channels/group and set the desired brightness
- 
- 
- 
- 
- Once A,B,C,D group selected or set fixtures on different channel, those different channel group fixture can be accessed and control brightness by IR remote.
- In order to access and control the fixture by remote > set or pointout selector switch towards A,B,C or D , If user set or indicator switch towards A, Press "A" button of the remote first then press "Full" or Brightness level buttons(10%,25%,50%,70% or 100%)
- If user set or indicator switch towards B, Press "B" button of the remote first then press "Full" or Brightness level buttons(10%,25%,50%,70% or 100%)
- If user set or indicator switch towards C, Press


# ZOOM & ANGLE




**RASHA** | Professional



**Figure 1**  
Bullet zoom without zoom



**Figure 2**  
Bullet with zoom  
"Softly pull the bullet head "Upwards  
at sky or push downward to set zoom  
angle"



**Figure 3**  
"Bullet with zoom and bend gooseneck  
Softly bend the gooseneck on required direction and  
angle to point projection on required object"

## PHYSICAL

|            |                  |
|------------|------------------|
| Weight :   | 1.2 lb           |
| Gose Neck  | 80 x 15 x 15 mm  |
| Head       | 63 x 63 x 45 mm  |
| Dimensions | 45 x 45 x 100 mm |

## DYNAMIC EFFECTS

|                    |                      |
|--------------------|----------------------|
| Color              | Warm White           |
| Electronic dimming | 10%/25%/50%/70%/100% |
| Color Temp         | 2800 K               |

## OPTICS

|   |                                      |
|---|--------------------------------------|
| Light source  | 1 x 10W Warm white LED Chip          |
| LEDs Beam angle   | 3°                                   |
| Mini LED Lifetime   | 50,000 hours ( >70% luminous output) |
| LED Manufacturer's figure obtained under manufacturer's test conditions |                                      |

## CONTROL AND PROGRAMMING

|                       |                            |
|-----------------------|----------------------------|
| Control options       | IR Wireless remote control |
| Brightness Selector   | 0%,10%,50%, 100%           |
| Manual Code selector  | A,B,C,D,Channels           |
| Remote type           | Superior IR Technology     |
| Controllable distance | 10 Feet                    |
| IR Remote channels    | 10 Channels                |

## CONSTRUCTION

|                   |                              |
|-------------------|------------------------------|
| Materials         | Body/Head(anodized Aluminum) |
| Gose Neck         | Thermal Plastic              |
| Color             | Black/White/Silver           |
| Basement Magnet   | Heavy duty magnet, Anodized  |
| Protection rating | IP20                         |

## INSTALLATION

|             |  |
|-------------|--|
| Mounting    | Magnetic surface, stick in any metal, O clamp surface or truss mount/free standing |
| Orientation | Any  |
| Location    | For indoor use only  |

## APPROVALS

|                            |   |
|----------------------------|---|
| EU safety                  | EN 60598-1, EN 60598-2-1, I EC/EN 60825-1 |
| EU EMC                     | EN 55103-1, EN 55103-2, EN 61000-3-2      |
| Canadian safety (US model) | CAN/CSA C.22.2 No. 250                    |

## CONNECTIONS

|                    |                                 |
|--------------------|---------------------------------|
| Charger power in   | Type N Barrel charge            |
| Channel selector   | A,B,C,D manual channel selector |
| IR Signal Receiver | Superior IR                     |

## ELECTRICAL

|                       |                              |
|-----------------------|------------------------------|
| AC power              | 100-240 V, 50/60 Hz 10W      |
| Power consumption     | High-powered Lithium battery |
| Battery               | Hours                        |
| Battery backup time   | 4 Hours                      |
| Battery charging time |                              |

## INCLUDED ITEMS

|  |  |
|--|--|
| Easy Pin                               |  |
| Remote control (1 Remote per 10 Units) |  |
| Charger                                |  |

## ACCESSORIES (SOLD SEPARATELY)

|                   |            |
|-------------------|------------|
| IR Remote         | P/N 891502 |
| Road Case 20 in 1 | P/N 901306 |
| Charge Saver      | P/N 901308 |

## ORDERING INFORMATION

|                                   |            |
|-----------------------------------|------------|
| Bullet pinspot Card Board Packing | P/N 820010 |
| 20 in Charging road Case          | P/N 820012 |



# RETURNS



You must send the product prepaid, in the original box, and with the original packing and accessories. Rasha Professional will not issue call tags.

Visit [www.rashaprofessional.com](http://www.rashaprofessional.com) to log into your account and request a Return Merchandise Authorization (RMA) number before shipping the product. Be prepared to provide the model number, your order number, serial number, and a brief description of the Claim(s) for the return.

Clearly label the package with an RMA number. Rasha will refuse any product returned without an RMA number.

DO NOT write the RMA number directly on the box. Instead, write it on a properly affixed label.

Once you have received the RMA number, include the following information on a piece of paper inside the box:

- Your name
- Your address
- Your phone number
- The RMA number
- A brief description of the problem(s).

Be sure to pack the product properly. Any shipping damage resulting from inadequate packaging will be the customer's responsibility.

Double-boxing is recommended. Rasha reserves the right to use its own discretion to repair or replace returned product(s).

# CONTACT US



HEADQUARTER - RASHA PROFESSIONAL A/S LLC

ADDRESS: 1800 Rustin Ave, Riverside CA 92507

Voice: +1 (951) 654 3585

Technical Support

Email: [Info@rashaprofessional.com](mailto:Info@rashaprofessional.com)

[www.rashaprofessional.com](http://www.rashaprofessional.com) | [www.rashalight.com](http://www.rashalight.com)

Outside the U.S. contact the dealer of record. Follow their instructions to request support or to return a product. Visit our website for contact details.

# NOTES



